


Non-Current Planter/Fertilizer Replacement Parts

AP-699031 – Nutri-Till Tube Kit



Part #	Qty Req	Description
AP-500405	4	1/4" x 5/8" carriage bolt Gr. 5
AP-500580	4	1/4"NC top lock nut
AP-698133	1	Tube mount bracket ❶
AP-699033	1	Weld, steel tube with mount ❷



**NOT CURRENT,
But all parts serviced**

AP-698031 – Nutri-Till Tube Kit


Part #	Qty Req	Description
AP-500430	4	1/4" x 1/2" carriage bolt Gr. 5
AP-500580	4	1/4"NC top lock nut
AP-698013	1	Tube mount bracket ❶
AP-699033	1	Weld, steel tube with mount ❷



AP-699015, AP-699110, AP-699111, AP-699115 Nutri-Till Disc Assemblies

Part #	Qty Req	Description
AP-299143	1	TW disc bearing flange open ❶
AP-299050	2	Gasket ❷
AP-299054	2	Bearing nutri-till ❸
AP-299164	1	TW disc bearing flange closed ❹
AP-500402	6	5/16" x 1" carriage Gr. 5 (not shown)
AP-500523	2	7/16" x 1-3/4"NC serrated flange bolt (not shown)
AP-500582	6	5/16"NC top lock nut (not shown)
AP-500583	2	7/16"NC top lock nut (not shown)
AP-500606	1	5/8"NF nylon insert lock nut ❺
AP-500633	1	5/8" diameter internal star washer (not shown)
AP-698043	1	NT bearing flange, open (not shown)
AP-698051	1	Retaining ring ❻
AP-698063	1	NT bearing stud ❼
AP-698065	1	Bearing spacer ❽
AP-699114	1	9" notched sub assembly ❾
AP-699016	1	NT stem VJ/VP 2 hole ❿

**NOT CURRENT,
But all parts serviced.
AP-699114 wheel
available smooth or
notched**



Non-Current Planter/
Fertilizer Replacement Parts